

















H515

SERVICE PLATFORM

EMERGENCY ESCAPE
PULL



EMERGENCY ESCAPE PULL

TO OPEN



EXTERNAL FREIGHT
CARRYING
CAPACITY
SLING PT NO





SERVICE PLATFORM

NO LOADING
FUEL
START - SEE MAINTENANCE
MANUAL

EMERGENCY EXIT - PULL

EMERGENCY EXIT - TURN

PICKET HERE

RADIO EQUIPMENT

DTD
5580

EXTERNAL FREIGHT
CARRYING CAPACITY
USING SLING
PT. NO. WA9-83-123
2,500 LBS













